




# Charge Amps **Aura**

## **User Manual**



Care for the environment! Must not be discarded with household waste! This product contains electrical or electronic components that should be recycled. Leave the product for recycling at the designated station e.g. the local authority's recycling station.



Disposal of the product must comply to the local environmental laws and guidelines. The product consists of recycled aluminium, plastic, and electronics, and should be recycled as specified for these materials.



Approved in accordance with the relevant EU directives.

Neglecting to follow and carry out the directions, instructions and safety precautions of this user manual implies that any warranty provisions will be cancelled and that Charge Amps AB can reject any and all claims for compensation in connection with any injuries/damage or incidents – direct or indirect – that are a result of such negligence.

The manufacturer does not give any warranties as to the accuracy or completeness of this document and shall have no liability for the consequences of use of such information. The manufacturer reserves the right to make changes to information published in this document without notice. Visit [www.chargeamps.com](http://www.chargeamps.com) for the latest document releases.

© Copyright Charge-Amps AB 2021. All rights reserved. Copying, amending and translating are strictly forbidden without prior written approval from Charge-Amps AB.

# 1. Safety

WARNING! Read all instructions before use.

- Improper use may create a risk of personal injury.
- The product must only be installed by a qualified electrician in accordance with the Installation Manual.
- National installation requirements and restrictions apply.
- Only use this product for charging compatible electric vehicles.
- Inspect the product for visible damage before use.
- Never attempt to repair or use the product if it is damaged.
- Do not immerse the product in water, subject it to physical abuse or insert foreign objects in any part of the product.
- Never attempt to disassemble the product in any way.

# 2. Technical Data


|                            |   |
|----------------------------|---|
| Article number             | 101010 / 101010-LTE*  |
| Charging standard          | Mode 3  |
| EV power supply identifier |  |
| Identification             | RFID( i/a) HF, 13.56 MHz  |
| Internet connection        | WiFi 802.11b/g/n, 2.4 GHz   |
| Metering                   | 3-phase voltage, current and power  |
| External RCD needed        | No  |
| Operating temperatures     | -30 °C to +45 °C  |
| Voltage                    | 230/400 V   |
| Sockets                    | 2 x 22 kW Type 2  |
| IK-rating                  | IK10  |
| IP-rating                  | IP55  |
| Dimensions (B x D x H)     | 367 x 159 x 405 mm  |

|                      |                            |
|----------------------|----------------------------|
| Weight               | 10 kg                      |
| RFID Frequency Range | 13.553 – 13.567 MHz        |
| RFID Output          | 31 dBm                     |
| WiFi Frequency Range | 2412 - 2484 MHz            |
| WiFi Output          | 802.11 b/g/n: 20/17/14 dBm |

|                              |                                      |
|------------------------------|--------------------------------------|
| *Specification of 101010-LTE |                                      |
| RF Technology                | GSM, GPRS, EDGE, UMTS/HSPA+, LTE     |
| Max RF output                | 32 dBm@GSM, 24 dBm@WCDMA, 23 dBm@LTE |
| RF Range                     | 698 - 868 / 1650 – 2690 MHz          |
| SIM card                     | Standard SIM                         |

## 3. Product Overview

### 3.1. Parts



- A. RFID reader
- B. RFID light
- C. EV socket
- D. Socket light
- E. Cylinder lock

### 3.2. Contents of the package

- Charge Amps Aura
- Cable slide with fittings, plugs and screw
- Two keys for the cylinder lock (*Only to be opened by a qualified installer during installation*)
- Two RFID cards
- Quick Guide User

## 4. Use

### 4.1. Cloud service & App

Charge Amps Cloud and Charge Amps App are available for Charge Amps Aura connected to Charge Amps as cloud provider.

For Charge Amps Auras connected to other cloud providers, please refer to your cloud provider for inquiries about portals and apps.

#### Charge Amps **App**



#### Charge Amps **Cloud**



<https://my.charge.space/>

Visit link to find full product documentation.



<https://www.chargeamps.com/product/charge-amps-aura/>

## 4.2. Add RFID card

Add RFID cards using the cloud service.

## 4.3. Charging without RFID identification

1. Connect the EV connector to the car. Lift the socket cover and connect the EV plug to the EV socket.
2. Disconnect the EV connector from the car and disconnect the EV plug from the EV socket.

## 4.4. Charging with RFID identification

1. Connect the EV connector to the car. Lift the socket cover and connect the EV plug to the EV socket.
2. Briefly hold the RFID card in front of the RFID reader to initiate charging.

If the other socket is not in use, it will turn dark and be unavailable for use during the 5 minutes RFID verification time window.

If no RFID card has been verified during the 5 minutes time window, charging needs to be initiated remotely or reactivated by unplugging and reconnecting the EV connector.

3. Disconnect the EV connector from the car and disconnect the EV plug from the EV socket.

## 4.5. Cable lock

During charging the cable lock is automatically activated.

To lock the EV charging cable to Charge Amps Aura while not charging, use Charge Amps App or Cloud Service.

## 4.6. Status Indications

| Status                          | Socket Light        | RFID Light                |
|---------------------------------|---------------------|---------------------------|
| Ready for charging              | Green light         | No light                  |
| Charging                        | Blue light          | Green light               |
| Waiting for load balancing      | Flashing blue light | No light                  |
| Waiting for RFID verification   | Yellow light        | Flashing blue light       |
| Charging complete               | Yellow light        | No light                  |
| RFID card not approved          | Yellow light        | Red/Flashing Blue light * |
| RFID verification timeout       | Yellow light        | Red light                 |
| Error                           | Red light           | Red light                 |
| EV socket not available for use | No light            | No light                  |

\* Auto return to *Waiting for RFID verification*

## 5. Maintenance

WARNING! Never spray water or any other liquid directly on the product.

### 5.1. Regular maintenance

- Visually check that the EV connector is free from damage.
- The outside of the product must be regularly wiped with a clean, dry cloth to remove dirt and dust.
- Do not use detergent to clean any of the product components.

## 6. Product support and service

If you have any questions or problems with the product, support is always available. To find answers to your questions most quickly:

Read through the user manual to check whether your questions are answered there.

1. If your question is not answered in the manual, please contact your supplier or cloud provider.
2. If you need service or repair, start by contacting the supplier from whom you purchased the product.
3. For additional information, see [chargeamps.com/support](https://chargeamps.com/support).

## 7. Warranty

As warranty terms may differ from market to market, we recommend that you contact your supplier regarding the warranty terms.